



Intelligent key strips.

Choose a lockable/non-lockable solution. Easily mounted on the wall or in a security cabinet.

NEW!



KEYRACK

Intelligent key strips for cabinet and wall mounting.

Pair your keys with the IntelliPin key peg and place them in the KeyRack system's lockable/non-lockable key strips, directly on the wall or in a cabinet. It couldn't be easier to obtain an overview and total control of your key stock. With KeyRack, you can expand your intelligent key storage up to a maximum of 66 strips with 924 unique key places. Get maximum overview by mounting directly on the wall or maximum security by mounting in one or more security cabinets – you choose.



The KeyRack system gives you flexibility, security and fast access. Store keys in open view or hidden in one or more security cabinets. Expand strip by strip as required.

Security is the primary consideration.

A flexible and easily installed solution for your security cabinets.


Easily mounted in rated cabinets.

Expand your system of key strips as required in one or more rated cabinets and at the same time secure the keys against theft and fire. Easy installation, easy key management and maximum overview of each individual key.



Mount directly on the wall

With the KeyRack key strip mounted directly on the wall, you obtain a guaranteed overview and fast access to each unique key. You can freely combine lockable/non-lockable strips and easily expand the system to meet your needs.




A complete range.

An expandable, transparent and lockable total solution.

Convenient control and overview, direct from your computer.

The KeyWin PC application keeps track of each separate key via the IntelliPin key peg. Pair the IntelliPin and key together, then place them on the strip on the wall or in a cabinet. Each separate IntelliPin carries a unique ID, which means you can easily identify the status of individual keys directly via your PC.



NEW

Choose between locked and unlocked key places for increased security.

Good order down to the smallest detail.

Identification

KeyRack recognises and identifies each individual key peg. A LED on the key strip also shows which key(s) are available with a given user's rights.

Intelligent key peg

Even if the actual IntelliPin key peg isn't intelligent, it is thanks to each peg's unique identity that all the possibilities open up.



Lockable/non-lockable peg

IntelliPin is available in two versions. Non-lockable pegs give an alarm immediately when the key is removed without authorisation first being given via the KeyWin software. Lockable pegs go a step further, and physically lock the key/peg in the strip. Both versions guarantee security and an overview of all your keys.

KEYWIN5 – Smart and easy.

KeyWin 5 software consists of only three views: Administration, Event log and Settings. Each is optimised to simplify your daily key management.

Administration

Gives you a quick overview, and the intelligent search function allows you to easily find the right user or key. Clicking on a key lets you instantly see which user and groups are connected to it. The same is true if you click a user or group.




Adding and managing users, groups and keys is simple and intuitive. To connect a user to a key, simply click on the key and choose “To Connect”. Then, just connect the groups and keys you want the user to have access to.

Event log

All events are registered in the log, both from the cabinet and KeyWin 5. Naturally, you can choose what will be displayed. The intelligent search function with selection and timeframe makes it easy to obtain the right information or create a report.

All alarms are indicated with red in the log and on the Event log tab. You get instant alarm indications and can simply see who or what has caused the alarm.



Settings

Settings lets you install a new cabinet, add a new administrator or make more advanced settings such as language, number of valid characters in codes, make backups and communication settings, and more.







Always upgraded

KeyWin5 is licence based – this means that you are always upgraded to the latest version. As soon as a new version is available, KeyWin asks you if you want to install it.

KeyWin is also available as a web application, which gives you the option to access the control program even from a computer on which the software is not installed.





Contact

If you would like more information, please contact us or one of our dealers. You can find more information and contact details for your nearest dealer at www.creone.com.

Creone AB

Tel.: +46 (0) 140 38 61 80

Fax: +46 (0) 140 38 61 89

Email: mailbox@creone.com

Office Address: Malmgatan 8, 573 38 Tranås, Sweden

Postal address: Box 148, S-573 22 Tranås, Sweden

Dealers